


## PowerEye Admin Portal User Guide: Login & Software Download

Once the account setup and license configuration have been completed, a notification email will be sent to the customer with login details.

Please access the portal at <https://admin.powereye.co/> and follow the instructions below to proceed.

### 1. Login to the System

1. Go to <https://admin.powereye.co/>
2. Enter your registered email address
3. Click **“Get authorization code”**
4. Check your email and enter the verification code
5. Click **Sign in** to access the system



**Note:** The verification code is valid for a limited time. Please check your Spam/Junk folder if not received.

Thank you for considering Power Eye – empowering your energy management with smart solutions.


© 2026 PowerEye System. All rights reserved.

Cập nhật gấp

**N** no-reply@cloud273.com  
Activation code  
Đến: mtecviet2008@gmail.com



Hộp thư...t2008 Gmail 12:22

Your activated code is **982299**.




## 2. Clients

- The **Clients** page displays a list of all registered clients (e.g. companies, factories).
- Each client entry includes key information such as name, email, phone number, address, and activation date.



## How to Download an Activation Key

1. Locate the desired client and click the **Document** icon in the corresponding row.
2. The **License** window will appear, showing all licenses assigned to that client.
  - o Each license includes: Key ID, issue date, feature type (e.g. Software, Monitor, Remote, Control, IIoT), and description.
3. Click the **Download** button (bottom-right) to download the activation key file.
4. Use the downloaded file to activate the PowerEye application.




The screenshot shows a web browser window with the URL `admin.powereye.co`. The page title is "License for PowerEye Demo PC". It displays a list of four licenses, each with a "Valid" status and a "Download" button (represented by a downward arrow icon) at the bottom right of the list.

Key ID	Type	Issued	Limit	Note
000e2df2-46cd-4c56-be49-c72cb4bd0439	Software	2025-03-06T10:45:25		Issue for MTECVIET DEMO
914c46e0-28f3-4764-98aa-b2ef8832bd06	Read/Write	2025-03-06T10:45:37	10 Devices	Issue for MTECVIET DEMO
63314f9b-e2b4-4dcf-8b26-8d4ddf59b2a4	Control	2025-03-06T10:45:43		Issue for MTECVIET DEMO
15bc4db3-040a-47d0-aac5-98f23b28d89b	Remote	2025-03-06T10:45:49	10 Users	Issue for MTECVIET DEMO

## 3. Download PowerEye Software

1. Navigate to the **Download** section from the left menu
2. Select the **latest version** (highest version/build number)
3. Click **Download**
4. The “**Download Setup Files**” window will appear. Select the required components:
  - a) **Power Eye** — required (main application)
  - b) **Power Eye Gateway** — required for Remote features
  - c) **Power Eye Broker** — optional (for IIoT/MQTT functionality)



## 4. Install Software on PC

1. Extract the downloaded file (if applicable)
2. Run **Power Eye Setup.exe**
3. If Windows displays a security warning → click **More info** → **Run anyway**
4. Follow the installation steps: **Next** → **Install** → **Finish**
5. Launch **PowerEye** after installation to start initial configuration

## 5. Activate License (Optional)

1. Go to the **Clients** section
2. Select the target client
3. Click the **License (Document)** icon
4. Download the activation key file
5. Import the key into PowerEye software to activate the system

## 6. Final Step

You can now start using the PowerEye system.  
For further assistance, please contact our support team.

## 7. Support & Assistance

Congratulations! You have completed the setup and activation of your PowerEye system. If you encounter any issues during the login, software installation, or license activation process, please reach out to our technical team for immediate help.

- Email Support: [contact@powereye.vn](mailto:contact@powereye.vn)
- Technical Documentation: <https://powereye.vn/partner-corner>
- Admin Portal Access: <https://admin.powereye.co/>

*Note: For security purposes, always ensure your activation keys are stored in a safe location and only shared with authorized personnel.*